


What is Veritas™ Access?

Veritas Access is a software-defined scale-out network-attached storage (NAS) solution for unstructured data that works on commodity hardware. Veritas Access provides resiliency, multi-protocol access, and data movement to and from the public or private cloud based on policies.

This document describes how to quickly deploy Veritas Access. For more complex installations, see the *Veritas Access Installation Guide*.

You can find the latest version of the product documentation on the [SORT website](#).

Veritas Access architecture



Before you begin


Hardware requirements:

- The hardware compatibility list (HCL) contains information on the supported hardware: <https://www.veritas.com/docs/000126344>
- Two servers, each with a minimum of:
 - 1 CPU – 64 bit, dual, or quad core, 2.0 GHz or above
 - 32 GB RAM – recommendation is workload-dependent
 - 60 GB + RAM size internally available storage capacity
 - Four 1-GB NICs with connectivity to all the nodes
 - 1 Fibre Channel HBA – 2 FC HBAs for HA (optional if using only DAS disks)

Software requirements:

- Operating system (OS):
 - Red Hat Enterprise Linux (RHEL) 6.6, 6.7, 6.8
 - At least nine IP addresses are required for a two-node cluster:
 - Four IP addresses for physical IPs
 - Four IP addresses for virtual IPs
 - One IP address for the management console

Example network configuration



Preparing the environment

1. Install the operating system (RHEL 6.6, 6.7, or 6.8) on each node of the cluster.

Installing Veritas Access

1. Log on to the node where you downloaded the Veritas Access installer. Use the root user and password.
2. Run the Veritas Access installer.
`# ./installaccess node1_ip node2_ip`
3. After installing the packages successfully, enter the information as prompted.

Enter the cluster name:
Enter the public IP starting address:
Enter the netmask for the public IP address
Enter the number of VIPs per interface:
Enter the virtual IP starting address:
Enter the default gateway IP address:
Enter the DNS IP address:
Enter the DNS domain name:
Enter the console virtual IP address:
Do you want to use the separate console port?
Enter the Network Time Protocol server:

Accessing the Veritas Access CLISH

1. After installation, connect to the management console using the console IP address you assigned earlier.
2. Log on using the following:
User name: `master`
Default password: `master`
You are prompted to change the password after your initial log on.
3. For subsequent log ons, use the user name `master` with the password that you have set. You can add additional users.

Accessing the Veritas Access GUI

The Veritas Access GUI is automatically installed with the Veritas Access installer. After the installation, a URL is generated. Open a browser window and copy in the generated URL <http://consoleIP:14161/> to access the GUI. See the online help for information on all the GUI operations. Click ? to access the online help.

The screenshot displays the Veritas Access 7.3 GUI. The top navigation bar includes a globe icon, the text 'Veritas™ Access 7.3', a 'Quick Actions' dropdown, and several utility icons (calendar, clock, notifications, help, and user profile). The main content area is divided into several sections:

- Overview:** Shows 'Provisioned Storage' with 'All Shares (4)' including 'NFS Share' (2 green, 0 red) and 'CIFS Share' (2 green, 0 red). Below this is 'File Systems (5)' with 'On Block Storage 49.13 TB' (Used: 503.66 GB, Available: 48.64 TB) and 'On Cloud Storage(S3/Glacier) 0 bytes'.
- Recent Alerts:** Lists two critical alerts about missing NBU master and media server configurations, and one warning about NTP being disabled.
- Configuration:** Includes options to 'Categorize disks into storage pools' and 'Configure backup'.
- My Favorite Shares:** A section with a blue plus icon and a prompt to 'Select your favorite shares to monitor Health, Performance, Capacity'.
- Performance:** Features a line graph for 'IOPS' (Read, Write, Total) over a 6-hour period, showing a peak around 12:30.
- NAS Infrastructure:** Shows 'Nodes (2)' (2 green, 0 red) and a 'CPU Utilization' graph (4% of 8 Cores Utilized) over 6 hours.